



Lamassu Bitcoin Machine

Mounting Instructions

v. 0.1.2

1. Open the machine by unlocking it on the side with the red key. Be sure to stabilize the machine, as the door is heavy.

2. Open the inner cash box vault with the blue key.



3. Remove the cashbox by pulling straight out on the green handle.

4. Use the allen wrench provided with the keyset to remove the screws on either side of the cashbox vault. (Screws have been removed in the image.)



5. These screws hold in a metal plate. Tilt the top of the plate towards you, and pull it upwards and outwards. Note: you may need to push on the bill validator mouth as there are two white plastic parts which can block the metal plate from being removed.



6. Once the plate is removed, disconnect the white connector that joins two sets of wires below the bill validator.



7. You can now slide the entire bill validator mechanism out of the machine.



8. Below where the validator was, you'll notice three holes for bolting down the machine, in addition to the two outside of the vault on right side.



9. You may use the plate provided as a washer in order to protect the machine and the surface you are mounting it on.

10. Mount screws such that the nuts are contained within the machine for security purposes.